VarioGPS JetiBox settings

Firmware V2.3

```
VarioGPS Sensor
Version V2.3
```

Wellcome screen and version of VarioGPS sensor

```
Reset offset
```

Press **DOWN** to reset all telemetry values to zero and to calibrate the offset of the current sensor

```
GPS mode:
 Extended
```

Press **UP/DOWN** to change GPS mode:
- Disabled
- Basic
- Extended

```
GPS distance:
 3D
```

Press **DOWN** to change GPS distance mode:
- 2D
- 3D

```
Pressure sensor:
 BMP280
```

Show detected pressure sensor

```
Vario smoothing:
 80%
```

Press **UP/DOWN** to adjust Vario smoothing filter

```
Vario deadzone:
  5cm
```

Press **UP/DOWN** to adjust Vario deadzone

```
Air speed:
 Enabled
```

Press **DOWN** to enable Air speed sensor

```
TEC mode:
 Air speed
```

Press **UP/DOWN** to change TEC mode:
- Disabled
- Air speed
- GPS

```
Main drive:
 APM2.5 90A/18V
```

Press **UP/DOWN** to select current/voltage sensor for main drive

```
Capacity reset:
 Auto
```

Press **UP/DOWN** to change Capacity reset mode:
- Startup
- Auto
- Manual

```
Rx1 voltage:
 Disabled
```

Press **DOWN** to enable Rx1 voltage sensor

```
Rx2 voltage:
 Disabled
```

Press **DOWN** to enable Rx2 voltage sensor

```
Ext. Temp:
 Disabled
```

Press **DOWN** to enable External temperature

```
Save and restart
```

Press **DOWN** to save all changed settings

```
Load defaults
```

Press **DOWN** to load default settings